

# RadonixPC+ CNC Control Card

## GMTCNT GSSF Servo Driver

### Connection Diagram

RadonixPC+ Pins	Description	GMTCNT GSSF Servo Pins	Description
1	VCC +24V	2	Com
2	Direction -	33	DIR -
3	Direction +	31	DIR +
4	Pulse -	29	PUL -
5	Pulse +	27	PUL +
6	Servo On	8	DIN3
7	Ready	1	Out+
8	Encoder zero		
9	Alarm Reset	16	DIN7
10	Ground	24 ve 3	GND ve Out -
11	Ground		
12	Ground		
13	Ground		
14	Ground		
15	Ground		